

Amazon Fire TV Stick

Change Your Fire TV's Language

To see menu text in your preferred language, change your Fire TV's language in the Settings menu.

1. Go to **Settings** on your Fire TV home screen.
2. Select **Preferences** from the **Settings** menu.
3. Select **Language**.
4. Use the **Down** button (below the **Select** button) to move down the **Languages** list.
5. Stop on the language you want and press the **Select** button.

The menu text on your Fire TV changes to your preferred language. Alexa's voice may change based on your chosen language option.

Note: Fire TV doesn't support all languages. Some features may be unavailable.