



Amazon Fire TV Stick

The Remote

Watch online streaming services like Netflix, Hulu, and Amazon Prime with the Amazon Fire TV Stick!

The Fire TV Stick has some built-in accessibility options for both low vision and screen reading. Use them to control your Fire TV Stick. **Try it out!**

Tip: Before you get started, you'll need to set up your Fire TV Stick. If you need information on how to do that, feel free to contact a Hadley specialist.

Tip: Using the Fire TV Stick requires a wireless Internet connection, or Wi-Fi, to connect to the streaming services. If you'd like information about setting up your Amazon Fire TV Stick on your TV, contact a Hadley specialist.

Reviewing the Buttons on the Remote

Tip: There are several different Fire TV Stick models, so if the buttons on your remote don't match what's in the workshop, contact a Hadley specialist for more information.

These are the buttons on your Fire TV Stick remote:

- **Power:** Top left corner of remote. Turns your Amazon Fire TV Stick on and off.
- **Alexa Voice:** Top center of remote. Use this digital assistant to find and launch shows.
- **Four-Way Directional Pad** surrounding a large center button:
 - **Top:** Press to move up.
 - **Bottom:** Press to move down.
 - **Left:** Press to move left.
 - **Right:** Press to move right.
 - **Center:** Press for **Select** or **OK**.
- First row of buttons below the pad, from left to right:
 - **Back:** Move back to a previous screen.
 - **Home:** Return to your home screen. This button has a raised tactile dot.
 - **Menu:** Press for context-specific menus.
- Second row of buttons below the pad, from left to right:
 - **Rewind**
 - **Play/Pause**
 - **Fast Forward**

- Third row of buttons below the pad, from left to right:
 - **Mute:** Turn sound off and on
 - **Volume:** Oval button. Press the top to raise the volume and the bottom to lower the volume.
 - **Guide:** Press once to open Amazon's guide for live TV. Press again to access live TV guides for your installed applications.
- At the bottom of the remote are two rows of buttons for quick access to favorite apps:
 - Top row: **Amazon Prime Video** and **Netflix**
 - Bottom row: **DIRECTV** and **Peacock**

Tip: The Fire TV Stick also has an **Explore Your Remote** screen reading feature. **Explore Your Remote** announces the names of your Fire TV remote buttons when you press them. If you'd like to learn more about how to turn on **Explore Your Remote**, contact a Hadley specialist.

Fire TV Stick Digital Assistant

1. Press and hold the **Voice** button. After the tone, say, "Open Prime Video." Then release the button.
2. Prime Video opens on its home/main menu screen.

Tip: The first time you open a streaming platform app, like Prime Video, you will be prompted to download it to your Fire Stick. After you press the Select button to download it, you're all set to play your favorite shows.

3. Press and hold the **Voice** button. Then say, "Play the Carol Burnett Show," or another show available on Prime Video.
4. If you haven't watched the show yet, it plays from the beginning. If you started watching it previously, it plays from where you left off.
5. To go back to the beginning of the show, press and hold the **Voice** button. After the tone, say, "Go to the beginning."

Tip: There are currently 40 commands you can use with the Voice button. Amazon adds new ones regularly. For more information on voice commands, contact a Hadley specialist.