



Amazon Fire TV Stick

Accessibility Features

Did you know that the Fire TV Stick has accessibility features?

Your Amazon Fire TV Stick offers various Accessibility Features that make it easier to use. **Try them out!**

Turning On VoiceView

VoiceView is Amazon's screen reader that reads aloud what is on the screen.

1. Press and hold the **Back** button and **Menu** button together. A tone sounds, and then VoiceView announces that it is ready.

Tip: When you use VoiceView for the first time, a tutorial runs, giving you helpful tips for using this feature. Check out the workshop on VoiceView for more in-depth information.

Accessibility Settings

2. Press and hold the **Voice** button. Then say, "Go to Settings."

3. Press the **Select** button in the center of the directional pad to open **Settings** options.
4. VoiceView gives you information about what is on the screen, with the focus on **Notifications**.
5. Press the **Right** button on the **Directional Pad** twice to move to **Account and Profile Settings**.
6. Press the **Down** button twice to move to **Accessibility** in the third row.
7. Press the **Select** button to open the **Accessibility** options.

Tip: Pressing the **Select** button turns each of the **Accessibility** features on and off. Turning one on moves you into a new list of options for that specific feature. When you're ready to move back to the main **Accessibility** menu, use the **Back** button on your remote.

8. Press the **Down** button until you reach **VoiceView**. This is where you manage voice output settings, like reading speed and volume.

Tip: For more detailed information about this feature, check out the workshop on **VoiceView** in this series.

Tip: The first two options you passed in the menu are **Closed Caption** and **Alexa Caption**. If you'd like more information about these features, contact a Hadley specialist.

9. Press the **Down** button until you reach **Screen Magnifier**. Then press the **Select** button. The screen zooms in and displays a list of shortcut keys for using this feature.
10. Press the **Right** button on the **Directional Pad** to move to the **OK** button on the screen.
11. Press the **Select** button on your remote. Now you can use the **Up** and **Down** buttons to move through the zoomed in **Accessibility** options list.
12. Press the **Back** and **Fast Forward** buttons together to turn off the **Screen Magnifier**.

Tip: For more information about the Screen Magnifier, check out the workshop on low vision features in this series.

13. Press the **Down** button to move to the next option, **High Contrast Text**.

Tip: This feature changes most of the text on the screen to black or white with a high-contrast border. Check out the workshop on low vision features in this series to learn more.

14. Press the **Down** button again to move to **Audio Description**.

Tip: This feature lets you add an audio track with verbal descriptions of images and actions for some shows, including Amazon Prime Video content and over-the-air channels. If this feature sounds interesting to you, check out the **Audio Description** workshop in this series.

15. Press the **Down** button once more to reach the final option, **Feedback and Support**. This option gives you an email address and phone number to contact the **Amazon Accessibility Support** team.
16. Press the **Home** button to return to your Fire TV home screen.