



Amazon Fire TV Stick

Low Vision Features

Did you know that the Fire TV Stick has built-in low-vision features?

The Fire TV Stick low vision features help make moving around its environment a little easier. **Try them out!**

Turning On the Screen Magnifier

1. Go to the home screen of your Fire TV Stick.
2. On your remote, press and hold the **Back** and **Fast Forward** buttons for two to three seconds.

Tip: The back button is the far-left button in the top row below the Directional Pad. The Fast Forward button is the far-right button in the second row below the Directional Pad.

3. The **Screen Magnifier** tutorial screen opens, with the focus on **Turn Off Magnifier**. Press the **Right** button to move to **OK**.
4. Press the **Select** button to turn on the **Screen Magnifier** and return to the home screen.

Tip: The Screen Magnifier is most useful for reading menus, notifications, and other text. It also lets you zoom in while watching movies and TV shows, but then you'll only see a portion of the onscreen action.

Zooming In and Out

5. To zoom in, press and hold the **Menu** button. Then press and release the **Fast Forward** button.
6. To zoom out, press and hold the **Menu** button. Then press and release the **Rewind** button.

Tip: Each press and release of the Fast Forward or Rewind button zooms in or out in increments.

Tip: When you zoom in or out, a visual indicator appears briefly at the top right corner of the screen, showing you which part of the screen is magnified. This indicator appears for a few moments each time you zoom in or out.

7. To view different areas of the screen, press and hold the **Menu** button. Then use the directional buttons to pan up, down, left, or right.
8. Use the directional buttons alone to move your selection. The magnification follows your movement.

Another Way to Turn on Screen Magnifier

9. Move to the **Home** icon on the home/main menu screen. Then press the **Right** button until you reach **Settings**.
10. Press **Select** to open **Settings**. The focus is on **Notifications**.
11. Press the **Down** button twice to move to the bottom row of the options grid.
12. Press the **Right** button twice to move to **Accessibility**. Then press the **Select** button to open the **Accessibility** menu.
13. The focus is on **Closed Caption**. Press the **Down** button repeatedly until you reach **Screen Magnifier**.

Tip: Now you know two ways to turn the Magnifier on and off. You can use the **Back + Fast Forward** button combination on your remote or select the **Screen Magnifier** option in the **Accessibility** menu.

Turning On the Text Banner

14. Press the **Up** button once to move to **Text Banner**.
15. Press the **Select** button to open the **Text Banner** tutorial screen.

16. Press the **Right** button to move to **OK**.
17. Press **Select** to open the **Text Banner** options menu. Here, you can:
 - Change the font size and color.
 - Change the banner size and timing.
 - Open the tutorial.
 - Return all of the settings to default.

Tip: For more information about the text banner options, contact a Hadley specialist.

Tip: You can also turn the Text Banner on and off by pressing and holding the **Rewind** and **Fast Forward** buttons together for two seconds.

Using the Remote to Control the Text Banner

18. Use these buttons on your remote to control the **Text Banner**:
 - **Rewind and Fast Forward:** Move back and forth through the text when there is more text than fits in the banner.
 - **Play/Pause:** Press and hold to hide the banner so you can use the **Rewind** and **Fast Forward** buttons for their normal functions. Press and hold the buttons again to unhide the banner.
19. Press the **Rewind** and **Fast Forward** buttons together to turn off the **Text Banner**.