



iPhone/iPad for Low Vision

Back Tap Feature

The Back Tap feature is an easy way to quickly perform actions on your iPhone using a double or triple tap on the back of the phone. Try it out!

Setting Up the Back Tap Feature

1. Make sure your device is running **iOS 14** or later.
2. Open the **Settings** app.
3. Scroll down to **Accessibility** and tap to open the **Accessibility** screen.
4. Scroll down and tap on **Touch**.
5. Scroll to the bottom of the screen and tap **Back Tap**.
6. Tap **Double Tap** or **Triple Tap**. Choose from the list of actions to set your taps.
 - For example, you can set the **Double Tap** to open the **Control Center** and the **Triple Tap** to take you to the **Accessibility Shortcut**. A check mark will show next to the action you select.

Tip: Back Tap doesn't allow multiple actions to be set for a double or triple tap.

7. Once you've chosen double and triple tap actions, try it out by tapping on the back of your phone to start the action.

Tip: Tap firmly on the center area of the back of your phone.

Tip: The Back Tap feature should work even if you have a case on your phone.